

Loading Printer

Open printer door.

Place roll in holder so that printed instructions face you upside down.


Cut paper so that it comes to a point as shown.

CUT PAPER DO NOT FOLD


Insert point of paper into top of printer until point comes through front.


Carefully pull point of paper directly toward top of unit until about 6 inches is fed through.


Feed paper completely through paper door and and secure door.





Setting Time, Day and Date:



Press  to open Menu screen & cursor will be on "Reset Loop".

Press  to move cursor to "Set Parameters".



Press  & enter 4 digit Access Code. Cursor is now at "Time/Store Hrs/Code".


Press  & cursor is now in the upper left corner of the screen.

Press  & cursor moves to the HOUR.


Press  or  to increase or decrease the HOUR(also adjusts AM/PM).

Press  to move to the MINUTES, DAY, MONTH or DATE.

Press  or  to adjust the setting until correct.


Press  to save all changes.

The cursor will now be on the line of the YEAR.

Press  to move to the YEAR.

Press  until the correct YEAR is set.

Press  to save change and  twice to return to the activity screen.

NOTE:  can be pressed at any time to save any changes made without going to each individual setting.

Resetting Printer

Press **PRINTER RESET** button.

Pressing the **KEYBOARD MODE** and **2/PRINT DISPLAY** keys on the keyboard at the same time also resets the printer.

Printhead will cycle back and forth then stop.

If Printer Jams


Carefully cut paper where it enters printer. Taking care not to put stress on printer parts, pull remaining paper from front of printer. Pull toward top of unit.


DO NOT USE ANY DEVICE (SCISSORS, SCREWDRIVER, ETC.) TO REMOVE PAPER.


Reset printer.


Repeat loading procedure.


Setting 1st Day of Week & Store Hours:


Press  to open Menu screen & cursor will be on "Reset Loop".


Press  to move cursor to "Set Parameters".


Press  & enter 4 digit Access Code. Cursor is now at "Time/Store Hrs/Code".



Press  & cursor is now in the upper left corner of the screen.


Press  to move cursor to 1st DAY OF WEEK.


Press  repeatedly until 1st DAY OF WEEK is correct.


Press  & cursor will move to SUN of the Store Hours.

Press  & cursor will be at opening time for SUN.

Press  or  to adjust OPEN time(also adjusts AM/PM, midnight is 12 AM).


Press  to move to MON and adjust time. Adjust all OPENING times first for MON - SAT.

Press  to move to the CLOSE time.

Press  until CLOSE time is set for SAT(also adjusts AM/PM, midnight is 12 AM).


Press  to move to closing time for FRI. Continue setting CLOSE times FRI - SUN.


Press  to save changes and  twice to return to the activity screen.


NOTE:  can be pressed at any time to save any changes made without going to each individual setting.

Remove Car from Line:


This feature is used if a car completely leaves the drive-thru after stopping at the menu board & before reaching Win2(pickup window).

Press  and the cursor will now be on "Reset Loop".



Press  to move the cursor to "Remove Car from Line".

Press  and enter the 4 Digit Access Code.

The cursor will now be to the left of "A SIDE" under "REMOVE 1 CAR".

Press  here to remove 1 car at a time


or


Press  until cursor is just to the left of "A SIDE" under "RESET LINE TO 0 CARS" and then press  to reset the running car count to 0.




Note: This will clear all actively timing cars out of the timer. Use with caution to ensure that actual cars are not cleared out.

Reset Loop:

If detection at one of the Windows locks on(L3, L4, L7 or L8 lit & time continues to run with no car present at that window), try resetting the loop for that window by following the Reset Loop instructions below.

Press  and the cursor will now be on "Reset Loop".

Press  and enter the 4 Digit Access Code.

Press  or  until the cursor is on top of the "A" for the appropriate window. Then press  and the L light for this window should turn off. Monitor & the L light should come back on when the next car arrives at the window and turn off when it leaves.

If the L light remains lit even though the car has exited the window, try resetting again. If problem continues, contact Phase Research Customer Service for troubleshooting assistance.