



**DR500 General Functions and Commands**  
**Channel**

- Recall- Press **LAST**.
- Scan Press **SCAN**.
- Select Enter the channel number using the **NUMERIC** keys.  
—OR—  
Use the **TUNE ▲** or **TUNE ▼** keys.

**Locally Managed Channels ( Adding / Deleting Channels)**

- Add Tune to the desired channel.  
Press **PRESET 940**.
- Delete Tune to the desired channel.  
Press **PRESET 950**.

**Clock**

Press **PRESET 100**.

**Dynamic Range**

- Check Tune to the desired channel.  
Press **PRESET 110**.
- Clear Press **PRESET 510**.  
Clears all dynamic range settings from memory.
- Set Tune to the desired channel.  
Press **PRESET 910**.  
Enter the dynamic range code and press **STORE**.
- Global Press **PRESET 960**.  
Enter the dynamic range code and press **STORE**.

**Forced Tune Events (Dayparting)**

- Check Tune to the desired channel.  
Press **PRESET 130**.
- Clear Press **PRESET 530**.  
Clears all forced tune event settings from memory.
- Set Tune to the desired channel.  
Press **PRESET 930**.  
Enter the hour and press **STORE**.

**Signal Quality**

Press **PRESET 180**.  
Press any key to clear display.

**Transponder Frequency**

- Check Press **PRESET 120**.
- Set Press **PRESET 920**.  
Enter the transponder frequency and press **STORE**.

**Volume**

- Set Adjust the volume using the controls on your stereo system.
- Mute Press **MUTE**.  
To return to normal volume, press **MUTE** again.

**DMX MUSIC/DJ View Functions and Commands**

- Audio Info. Press **VIEW**.  
Press **MORE** to see additional information.
- DR500 Status Press **PRESET 150** and press **VIEW**.  
Press **MORE** to see additional information.
- Time Press **PRESET 100** and press **VIEW**.
- Unit ID Press **PRESET 190** and press **VIEW**.

**DR500 PRESET Commands and Functions**

- PRESET 100 Check the DR500 clock.
- PRESET 110 Check the dynamic range for a selected channel.
- PRESET 120 Check transponder frequency.
- PRESET 130 Check the forced tune event for a selected channel.
- PRESET 150 Check status of DR500.
- PRESET 160 Toggle LNB Power Supply On/Off.
- PRESET 180 Check the signal quality.
- PRESET 190 Check DR500 Unit ID Number.
- PRESET 510 Clear all dynamic range settings from memory.
- PRESET 530 Clear all forced tune event settings from memory.
- PRESET 910 Set the dynamic range for a selected channel.
- PRESET 920 Set transponder frequency.
- PRESET 930 Set the forced tune event for a selected channel.
- PRESET 940 Add authorized channels.
- PRESET 950 Delete authorized channels.
- PRESET 960 Set global dynamic range.
- PRESET 970 Front panel lockout.
- PRESET 975 Volume control.

