


RESET BUTTON



Loop Board

Ethernet Board

Loop board should only be reset when there is no car at the window. To reset either board, give the button a good push and let go. This picture shows the "Connect Me" ethernet card and the EDI style loop board. If you have a different loop board, please refer to the "Fast Track loop board ID" document. If you have a different ethernet card, refer to the "Fast Track ethernet ID" document.