


## Loop Board Identification

There have been several different versions of the Loop Board over the years. Use this guide to correctly identify yours and to see where the Reset pushbutton is located.

Note that the two Loop Boards on the bottom are older and have no Reset pushbutton. If your Fast Track timer has one of these older Loop Boards the entire timer must be powered down and then back up to reset the Loop Board.



w/ Reset Switch labeled



w/ Reset Switch



no Reset Switch



no Reset Switch